SKYTRON

STELLAR/HERMES - VOICE ACTIVATION REMOTE CONTROL

Skytron's Digital Touchpad Wall Control Assembly allows remote control for ON/OFF and Intensity adjustments.

Connectors are provided on the Wall Control for connection to the HERMES™ Voice Activated control system.

Wall Controls are available for Skytron Stellar series single, dual or triple lighthead systems. The triple wall control is used for applications such as CVOR or ORTHO where three lightheads are utilized in either a triple lighthead fixture or a combination dual lighthead fixture with a single lighthead fixture.

Voice commands can control the Power ON/OFF and incrementally control Intensity level of each individual lighthead or all lightheads simultaneously.

Connection to HERMES™ voice activation system is accomplished via USB type cabling to the internal or external connectors on the Digital Touchpad Wall Control.

Existing Stellar series light fixtures can be upgraded by changing the existing wall control faceplate and installing the corresponding device driver software. All of the necessary components (including the device driver software) for connection to the HERMES™ system are included in the wall control faceplate kit.

HERMES™ Stellar Light Kit for **NEW installations** includes the Wall Control Assembly, the HERMES™ interface card and 50' of cable.

ST23 models B9-410-60
ST2323 models B9-410-61
ST232323 models B9-410-62
ST29 models B9-410-63
ST2923 models B9-410-64
ST292323 models B9-410-65

HERMES™ Ready, Stellar Light Kit for **EXISTING installations** includes the Wall Control Faceplate Assembly, the HERMES™ interface card and 50' of cable.

ST23 models B9-410-66
ST2323 models B9-410-67
ST232323 models B9-410-68
ST29 models B9-410-69
ST2923 models B9-410-70
ST292323 models B9-410-71

SINGLE AND DUAL LIGHTHEAD



TRIPLE LIGHTHEAD



REFER TO STELLAR DATASHEET FOR FIXTURE DETAILS